



www.GRAVESPORT.com
Tel (818) 902-1942 Fax (818) 902-3821

7629 Densmore Avenue
Van Nuys, CA 91406

ABY-08WR2-S

Smog Block-Off Kit Yamaha WR250R/X (2008-2011)

PARTS LIST

Airbox Plug	1
Block-Off Plate	1

THIS KIT IS FOR CLOSED-COURSE COMPETITION USE ONLY AND IS A MODIFICATION TO THE STANDARD EMISSIONS SYSTEM

<<<<<< IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>>

1. Disconnect PAIR valve hoses from both the airbox and metal fitting near the exhaust port.
2. Remove PAIR valve and hoses. (see Photo 1)



Photo 1 - These parts are removed from the motorcycle.

3. Unbolt the fitting from near the exhaust port. Be careful not to damage the stock gasket.
4. Install rubber plug on the uncovered airbox fitting. Be sure to use an adhesive or affix a hose clamp. (see Photo 2)



Photo 2 - Install rubber plug onto airbox.

5. Install new block-off plate in place of the factory fitting. Reuse the stock gasket. Torque to **8 Nm (6 ft-lbs)** using Loctite. (see Photo 3)



Photo 3 - Install block-off plate onto cylinder head.